

LogiLink_®

Door Stop Alarm

Art. No.: SC0208

Prevents doors from opening and alerts you of an attempted entry while you are at home or at hotels. This is a portable and effective home security system that you can take anywhere.

Features:

- » Prevents doors from opening and alerts you of an attempted entry
- » Alarm siren sounds at 120dB
- » Easy security system for dorms, hotels, apartments or
- » Trigger has three levels of sensitivity at High, Medium, and
- » Use as a door stop when power is off
- » Compact and light-weight for travel use
- » No installation required
- » Requires a 9V battery (not included)
- » On/Off switch to prevent activation while in luggage
- » High Quality durable ABS plastic and stainless Steel Cover
- » Dimensions: 138 x 46 x 40mm
- » Weight: 150g

Battery Installation:

Make sure to turn the switch to "OFF". Remove the cover of the battery case on the rear side. Insert a 9V battery (not included) into the battery case according to the correct polarity.

Instructions:

- (1) Place the unit on the floor below the doorknob with the low end of the unit under the door.
- (2) Slide the switch to "ON" to activate the alarm.
- (3) Slide the sensitivity switch to select the motion sensitivity from H (high), M (medium) or L (low).
- (4) Slide the switch to "OFF" to deactivate it.




















LogiLink_®

Door Stop Alarm

Art. No.: SC0208









Package Contents:

» 1 x Door Stop Alarm



» Packing Dimension: 229mm x 127mm x 50mm

» Packing Weight: 0,125kg

» Carton Dimension: 480 x 370 x 270mm

» Carton Q'ty: 40pcs» Carton Weight: 5,7kg



Warning:

At close range the siren may cause ear damage. When travelling or when not using the unit, be sure to turn the switch to "OFF". Requires a 9V battery (not included)





